

UNPACKING

Make sure that the packaging is undamaged. The device as well as the accessories are protected and / or fixed for transport. After opening the packaging, remove the packaging material and any transport securing devices in the form of adhesive tapes or cable ties.

Then check that the delivery is complete and make sure that neither the unit nor the accessories are damaged.

Keep the unit's packaging. The device can only be transported safely in its original packaging. If it is not possible to store the packaging, separate the various packaging materials and return them to the nearest collection point for proper disposal.

Although the device has been cleaned from the inside before it was shipped, it is still necessary to clean the interior before filling it with merchandise.

STRUCTURE

Place the unit in a dry and adequately ventilated room. Ensure that you stand securely on a dry and non-slip surface.

Place the unit with the rear side at least 10 cm away from the wall to ensure sufficient air circulation at all times. There should be at least 30 cm of space above the unit; 2 cm to the sides.

Performance and power consumption may be affected by ambient temperature or direct sunlight. Do not expose the unit to direct sunlight and do not place it near a stove, radiator or other heat source.

Ensure that the mains plug is always freely accessible and can be disconnected from the mains without any problems.

Set up the shelves of the appliance so that the distances correspond to the height of your goods.



Please wait 24 hours before switching on the device. During this time, we recommend that you leave the door open to remove any residual odours.

AFFILIATION

Connect the unit only to a grounding socket outlet with an earthing and a 230 volt connection.

Before connecting the device, make sure that the voltage and frequency of the power supply correspond to the information on the nameplate! Other voltages can lead to overheating of the device!

